

Silva Cell Installation Guide

Parts of the Silva Cell

Top to Bottom:

Deck

1X Post

2X Post

Base



Base



Post Sizes



0.5X




1X



2X




3X
(1x + 2X)




Deck

(permanent top)



Strongback

(temporary top)



Geotextile Fabric



Geogrid



Plastic Cable Ties



Anchoring Spike



Root Barrier (Guide)



Materials needed to install Silva Cell


Materials Supplied by DeepRoot

- Silva Cell bases
- Silva Cell decks
- Silva Cells posts
- Silva Cell anchoring spikes
- Strongbacks
- Root Barrier


Other Material Needed

- Geogrid
- Geotextile
- Plastic cable ties
- Compactable fill for outside Silva Cells
- Aggregate base
 - Below Silva Cells
 - Above Silva Cells
- Planting soils
 - For inside Silva Cells

Example - 2X + standard concrete pavement section



Example - 2X + standard paver section




Excavate the Silva Cell area



Make sure excavation is deep enough to accommodate subbase aggregate + Silva Cells + pavement section

Compact bottom of excavation (subgrade) before placing fabric and subbase aggregate

Over excavate a minimum of 300mm on all sides to allow for working room and proper compaction



Install the geotextile fabric



Place a layer of geotextile fabric over the compacted subgrade before placing the subbase aggregate

The geotextile fabric is an important component of the overall Silva Cell system and it is essential for establishing a uniformly stable subbase



Fine grade the subbase aggregate to a uniform elevation or slope.

Properly preparing the subbase is a critical step in the installation. If the Silva Cell frames do not sit level the legs will become misaligned making it difficult or impossible to attach the decks.

Place and compact the sub base aggregate layer



Place the required thickness of subbase aggregate over the geotextile fabric

Water and compact the subbase aggregate to 95% standard proctor density or as specified.


Lay out the bases



Mark out the
inner dimensions
of the tree opening




Make sure curb or thickened
Pavement edge at tree opening
is fully supported by Silva Cells




1.Start by placing frames around the perimeter of the tree opening where starting

2.Next place frames at the perimeter of the next tree opening




3.Then fill in-between using the quantity of Silva Cells shown in the drawings and space accordingly. The minimum space is 25mm. The maximum space should not exceed 150mm.





Anchor the bases



Anchor bases in place with 2 spikes per base

Install the sub drain

(When applicable)



Attach the legs



Insert leg into base and twist into place



Locking mechanism
snaps into place




Install the Strongbacks



Install Geogrid Around the Perimeter

The geogrid keeps the soil contained within the Silva Cell system as you fill it.

Wrap the geogrid around the outside perimeter like a fence






Attach geogrid with a cable tie at the top of each post to keep geogrid in place during backfilling

Install the first lift of Backfill Material


Anchor down the toe of the geogrid by placing backfill material to approximately the mid point of the leg but do not compact yet





Install the first lift of planting soil

Install planting soil mix to approximately mid point of legs. Level out and compact by walking over.








Compact the first lift of Backfill Material

After the first lift of soil has been installed and walked in go back and compact the backfill material first placed around the perimeter. Add additional material and compact until the backfill is approximately the same height as the soil in the cells





Keep compaction equipment from coming into direct contact with the legs to avoid potential damage.


Install the distribution pipe

(When applicable)



Start the process over by Installing more loose backfill material around the perimeter


After backfill material has been placed and compacted to the height of the soil inside the cells the process of adding backfill material around perimeter and soil in the cells repeats itself. This time leaving the backfill material ~75mm down from the top of the legs. Don't compact.






Place second lift of soil mix inside

Place 2nd lift of soil mix and walk in until the soil inside is level with the bottom of the strongbacks.



Add the post (for 3X systems)


For a 3X system carefully remove the strongbacks and add 1X post extensions. Then repeat the process of placing backfill material around the perimeter and then filling the cells with soil one additional time.





Remove the strongbacks and install the decks

When finished installing and walking in the soil carefully remove the strongbacks, level out the soil, and attach the decks











Fold over the excess geogrid

After installation of the decks fold the excess geogrid at the top over onto the decks and hold down with cable ties as needed.






Compact around the perimeter



Install geotextile fabric over the Silva Cells

Cover Silva Cells with Geotextile Fabric

Extend geotextile fabric to also cover the backfill area



Install the Aggregate Base Course Over the Silva Cells



Do not operate machinery over the Silva Cell System.

The Silva Cell system does not attain its load bearing capacity until the final pavement surface is in place.

Place the aggregate from outside of the perimeter of the system.

Start at one end and work continuously toward the other end. This keeps the geotextile fabric loose and allows it to be pulled down into the openings in the decks.

Compact the Aggregate Base



Compact the base aggregate as specified with equipment weighting 1,000 Lbs. or less


Install Permanent Pavement



Install Root Barrier



Install root barrier so
that the top is
~25mm down from
top of finished
pavement





THANK YOU!

Pat Greeley's Contact Information

pat@deeproot.com

Cell Phone: (612) 840-9004